Basic Network Sniffer

Requirements for Building a Network Sniffer in Python on Linux:

Software Requirements

1. Operating System:

- Linux (any distribution, e.g., Ubuntu, Debian, Fedora, etc.)

2. Python:

- Python 3.x (Ensure you have Python 3 installed)

3. Python Libraries:

- Scapy: A powerful library used for network packet manipulation and analysis.
- **pip:** Python package installer to install Scapy.

Hardware Requirements

1. Network Interface:

- A network interface (wired or wireless) to capture network packets.

2. Sufficient Permissions:

- Root or administrative privileges are required to capture network packets.

Step-by-Step Setup Guide

1. Install Python and pip

Most Linux distributions come with Python pre-installed. Ensure you have Python 3.x installed First Run kali linux and open terminal. Now type following commands:



Command: sudo apt update

```
cyber@kali: ~
  –(cyber⊛kali)-[~]
$ sudo apt update
[sudo] password for cyber:
Get:1 http://kali.download/kali kali-rolling InRelease [41.5 kB]
Get:2 http://kali.download/kali kali-rolling/main amd64 Packages [19.9 MB] 18% [2 Packages 1,144 kB/19.9 MB 6%]
```

sudo apt install python3 python3-pip Command:

```
Use 'sudo apt autoremove' to remove them.
0 upgraded, 0 newly installed, 0 to remove and 1361 not upgraded.
```

Verify the installation:

Command: python3 -version

```
__(cyber⊕ kali)-[~]

$ python3 --version

Python 3.11.8
```

Command: pip3 -version

```
cyber⊕ kali)-[~]

$ pip3 --version

pip 24.1.1 from /usr/lib/python3/dist-packages/pip (python 3.11)
```

2. Install Scapy:

Install Scapy using following pip command:

Command: pip3 install scapy

```
cyber⊕kali)-[~]

§ pip3 install scapy

Defaulting to user installation because normal site-packages is not writeable

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/bs4-0.0.2-py3.11.egg is deprecated. pip 24.3 will enforce this behavious ement is to use pip for package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/roguehostapd-1.1.2-py3.11-linux-x86_64.egg is deprecated. pip 24.3 will enge. A possible replacement is to use pip for package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/pwnedpasswords-2.0.0-py3.11.egg is deprecated. pip 24.3 will enforce this beha eplacement is to use pip for package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/Profil3r-1.0.5-py3.11.egg is deprecated. pip 24.3 will enforce this beha eplacement is to use pip for package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/argparse-1.4.0-py3.11.egg is deprecated. pip 24.3 will enforce this behave a placement is to use pip for package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/trio-0.25.1-py3.11.egg is deprecated. pip 24.3 will enforce this behave a seminated and the proper package installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/future-1.0.0-py3.11.egg is deprecated. pip 24.3 will enforce this behave a seminated by the propackage installation. Discussion can be found at https://github.com/pypa/pip/issues/12330

DEPRECATION: Loading egg at /usr/local/lib/python3.11/dist-packages/sublatar-1.0-py3.11.e
```

3. Create the Network Sniffer Script

Create a file named `network_sniffer.py` and add the following code

This Script with Logging and Filtering Here's the complete script with filtering and logging:

Script:

```
from scapy.all import sniff, Raw
from scapy.layers.inet import IP, TCP, UDP, ICMP
def packet_callback(packet):
  with open("packet log.txt", "a") as f:
    if IP in packet:
      ip_src = packet[IP].src
      ip_dst = packet[IP].dst
      protocol = packet[IP].proto
      f.write(f"IP Packet: {ip src} -> {ip dst} (Protocol: {protocol})\n")
      if TCP in packet:
        tcp_sport = packet[TCP].sport
        tcp_dport = packet[TCP].dport
        f.write(f"TCP Packet: {ip src}:{tcp sport} -> {ip dst}:{tcp dport}\n")
      elif UDP in packet:
        udp sport = packet[UDP].sport
        udp_dport = packet[UDP].dport
        f.write(f"UDP Packet: {ip_src}:{udp_sport} -> {ip_dst}:{udp_dport}\n")
      elif ICMP in packet:
        icmp_type = packet[ICMP].type
        f.write(f"ICMP Packet: {ip_src} -> {ip_dst} (Type: {icmp_type})\n")
      if Raw in packet:
        raw_data = packet[Raw].load
        f.write(f"Raw Data: {raw_data}\n")
if ___name___ == "___main___":
  print("Starting the packet sniffer...")
  # Filter for only TCP packets and start the sniffer
  sniff(prn=packet_callback, store=o, filter="tcp")
```

Here are the full detail about script:

Import Necessary Libraries:

Python

```
from scapy.all import sniff, Raw
from scapy.layers.inet import IP, TCP, UDP, ICMP
```

- -This line imports the required libraries:
 - scapy.all: Provides functions for packet manipulation, sniffing, and sending.
 - scapy.layers.inet: Defines network layer protocols like IP, TCP, UDP, and ICMP.

Packet Callback Function:

Python

```
def packet_callback(packet):
    # ...
```

-This function is called for each captured packet. It processes the packet and writes information to a file.

File Handling:

Python

```
with open("packet_log.txt", "a") as f:
#
```

-This line opens a file named "packet_log.txt" in append mode ("a"). Any data written to this file will be added to the end of the existing content.

Packet Analysis:

Python

```
if IP in packet:
    # ...
```

-Checks if the captured packet is an IP packet. If it is, it extracts IP-related information.

Python

```
ip_src = packet[IP].src
ip_dst = packet[IP].dst
protocol = packet[IP].proto
f.write(f"IP Packet: {ip src} -> {ip dst} (Protocol: {protocol}) \n")
```

-Extracts the source and destination IP addresses and the protocol type from the IP header and writes them to the file.

Protocol-Specific Information:

Python

```
if TCP in packet:
    # ...
elif UDP in packet:
    # ...
elif ICMP in packet:
    # ...
```

Checks the protocol type and extracts additional information based on the protocol:

- **TCP:** Extracts source and destination port numbers.
- **UDP:** Extracts source and destination port numbers.
- **ICMP:** Extracts the ICMP type.

The extracted information is written to the file.

Raw Data Extraction:

Python

```
if Raw in packet:
    raw_data = packet[Raw].load
    f.write(f"Raw Data: {raw data}\n")
```

Checks if there's raw data in the packet and writes it to the file.

Main Execution:

Python

```
if __name__ == "__main__":
    print("Starting the packet sniffer...")
    sniff(prn=packet_callback, store=0, filter="tcp")
```

This block starts the packet sniffing process:

- Prints a message indicating the start of the sniffer.
- Calls the sniff function to capture packets.
 - o prn=packet_callback: Specifies the packet_callback function to be called for each captured packet.

- o store=0: Prevents Scapy from storing captured packets in memory.
- o filter="tcp": Filters for only TCP packets.

Code Functionality:

This code captures network packets, extracts information about IP, TCP, UDP, and ICMP packets, and writes the extracted data to a text file. It focuses on TCP packets due to the filter applied.

-Let's Try this python Script:

Command: sudo python3 network_sniffer.py

```
(cyber@kali)-[~/Desktop/NetworkSniffer]
$ sudo python3 network_sniffer.py

[sudo] password for cyber:
Starting the packet sniffer...
```

-It will sniff the packets and create a separate file.



-Let's check this file

```
1 IP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
2 TCP Packet: 192.168.163.142 → 34.160.144.191:443
3 IP Packet: 192.168.163.142 → 34.117.188.166 (Protocol: 6)
4 TCP Packet: 192.168.163.142 → 34.117.188.166 (Protocol: 6)
5 TP Packet: 34.160.144.191 → 192.168.163.142 (Protocol: 6)
6 TCP Packet: 34.160.144.191 → 192.168.163.142 (Protocol: 6)
8 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
10 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
11 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
12 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
13 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
14 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
15 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
16 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
17 TCP Packet: 192.168.163.142 → 34.160.144.191 (Protocol: 6)
18 TCP Packet: 34.160.144.191 → 192.168.163.142 (Protocol: 6)
19 TCP Packet: 34.160.144.191 → 192.168.163.142 (Protocol: 6)
19 TCP Packet: 34.117.188.166 + 192.168.163.142 (Protocol: 6)
19 TCP Packet: 34.117.188.166 + 192.168.163.142 (Protocol: 6)
19 TCP Packet: 34.117.188.166 + 192.168.163.142 (Protocol: 6)
19 TCP Packet: 192.168.163.142 → 34.117.188.166 (Protocol: 6)
19 TCP Packet: 192.168.
```

Our Script is running perfectly and capture packets.